# Screwdrivers - Clutch type: SLIP-TRK

STRAIGHT SCREWDRIVERS - ERGOVIT series

WATT: 220

Hexagonal coupling: 1/4”

Data sheet

**ERGOVIT55D**



## Description

Slip clutch. In this case the clutch is adjusted using the Allen keys provided. This solution is ideal for those situations where a simple system for adjusting the tightening torque is required. Various adjustment ranges can be obtained by simply changing the springs. Models for use in wider than standard ranges are supplied with an extra spring. In those cases where frequent changes to tightening torques are required, we recommend that you use a tool equipped with a series of clutch units each set to a particular torque; when you need to change torque setting, just change the clutch unit. When ordering, use the codes indicated in the table.

## Technical specification

| | |
|---|---|
| Model | ERGOVIT55D |
| Code | 8301075 |
| No-load speed - rpm/min | 420 |
| Screw tightening - Metal | 8 |
| Screw tightening - Wood | 5,5x50 |
| Torque - Nm | 13,5 |
| Spring colour - * | Neutral |
| Length - mm | 262 |
| Body - ø mm | 38 |
| Air connection | 1/4”GAS |
| Weight - Kg | 1,06 |
| Hose - ø min mm | 8 |
| Air consumption - Nl/min | 430 |

# Screwdrivers - Clutch type: SLIP-TRK

STRAIGHT SCREWDRIVERS - ERGOVIT series

WATT: 220

Hexagonal coupling: 1/4”

Data sheet

**ERGOVIT55D**

## Overall dimensions

